



**SOLUTIONS**  
automotive security  
www.hf-solutions.co.uk



# Introduction of a New Transmitter

Firstly the Code Card **must** be available for the programming of a replacement transmitter.

You will also require a **working** transmitter, that is capable of 16 **consecutive** operations.( 8 x ON/OFF )



The new transmitter must then be programmed to the next free location within the alarm memory, 3 \* ,4\* ,5\* ,6\* , 7\*.

Its location will depend on the amount of transmitters already programmed to the alarm system.



With the working transmitter, operate the alarm ON/OFF 8 times.  
After these the alarm will stop locking/unlocking the vehicle.

The alarm is now in learning mode: -

1. Press the new transmitter, the indicators will flash to show acceptance.
2. Within 8 seconds press the original transmitter, again indicators will flash.
3. Repeat with any other transmitters that work the alarm.
4. After 20 seconds the alarm will drop out of learn mode.
5. Test each transmitter in turn.
6. Any that were not present during this learn procedure will no longer work the alarm, i.e. lost or stolen.

Should the transmitter not be accepted by the alarm system, it could either be the location has already been occupied or the transmitter code is incorrect.

If unsure of the amount of previous transmitters associated with the alarm, select a high transmitter location 5,6,7.

Optional Key Conversion  
OPEL/VAUXHALL only



54 Well Street, Langham, Oakham, Rutland LE15 7JS. Mobile: 07721654829

email:info@hf-solutions.co.uk

*Helping Keep TVR On The Road*